

# **LED Wall Wash 18x18W RGBWA+UV Lighting**



**Please carefully read the product description before use**

## **Maintenance**

1. Please keep the light in dryness and avoiding use in wet place.
2. Using intermittently can be extended the life.
3. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
4. Please do not wipe the crust using organic menstruum for avoid to damaged the product.

## **Statement**

The product has well capability and intact packing when leave factory, All of the user should comply with above warning item and manual ,any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual.

Please forgive that we will not be notice for technical change

## Attention Item

1. For guarantee the life of product, please don't put it on the wet place and not use it the place over 40 degree.
2. Please don't lay the product on the un-fixable or shakable place.
3. Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.
4. Power supply should not be changed over  $\pm 10\%$  while the light is using, it will be decreased the life of lamp if the power is too high, but it will be influenced the luminosity if the power is too low.
5. After power off, if it is need used again, please cool down over 20 minuter.
6. Please look round the manual for ensure the product can be used normally.

## DMX Channel Summary-10 Channels Mode

Channel	Value	Function
CH1	0-255	R, G, B, W, Y, P total dimming, linear dimming, from dark to bright
CH2	0-255	R, G, B, W, Y, P total strobe, from slow to fast
CH3	0-35	0--35: None
	36-45	36--45: Colorful Flowing Water (Jumping)
	46-55	46--55: Colorful Flowing Water (gradient)
	56-65	56--65: Color selection
	66-75	66--75: Transitions
	76-85	76--85: Gradient, pulse change
	86-95	86--95: Gradient running pattern 1
	96-105	96--105: Gradient Running Pattern 2
	• • •	• • • • • • • •
	146-155	146--155: Gradient running pattern 7
	156-165	156--165: Running Pattern 8
	• • •	• • • • • • • •
	236-245	236--245: Running Pattern 15
246-255	246--255: voice control	
CH4	31-45	31--45: Running Pattern 1
	46-60	46--60: Running Pattern 2
	• • •	• • • • • • • •
	240-255	240--255: running pattern 15
CH5	0-255	CH4 function speed, from slow to fast
CH6	0-255	R dimming, linear dimming, from dark to bright
CH7	0-255	G dimming, linear dimming, from dark to bright
CH8	0-255	B dimming, linear dimming, from dark to bright

CH9	0-255	W dimming, linear dimming, from dark to bright
CH10	0-255	Y dimming, linear dimming, from dark to bright
CH11	0-255	P dimming, linear dimming, from dark to bright

## DMX Channel Summary-29 Channels Mode

Channel	Value	Function
CH1	0-255	R, G, B, W, Y, P total dimming, linear dimming, from dark to bright
CH2	0-255	R, G, B, W, Y, P total strobe, from slow to fast
CH3	0-35	0--35: None
	36-45	36--45: Colorful Flowing Water (Jumping)
	46-55	46--55: Colorful Flowing Water (gradient)
	56-65	56--65: Color selection
	66-75	66--75: Transitions
	76-85	76--85: Gradient, pulse change
	86-95	86--95: Gradient running pattern 1
	96-105	96--105: Gradient Running Pattern 2
	• • •	• • • • • • • •
	146-155	146--155: Gradient running pattern 7
	156-165	156--165: Running Pattern 8
	• • •	• • • • • • • •
	236-245	236--245: Running Pattern 15
246-255	246--255: voice control	
CH4	31-45	31--45: Running Pattern 1
	46-60	46--60: Running Pattern 2
	• • •	• • • • • • • •
	240-255	240--255: running pattern 15
CH5	0-255	CH4 function speed, from slow to fast
CH6	0-255	R dimming, linear dimming, from dark to bright
CH7	0-255	G dimming, linear dimming, from dark to bright
CH8	0-255	B dimming, linear dimming, from dark to bright
CH9	0-255	W dimming, linear dimming, from dark to bright
CH10	0-255	Y dimming, linear dimming, from dark to bright
CH11	0-255	R, G, B, W, Y, P dimming
CH12	0-255	R, G, B, W, Y, P dimming
CH13	0-255	R, G, B, W, Y, P dimming
CH14	0-255	R, G, B, W, Y, P dimming
• • • • •	• • • • •	• • • • • • • •
CH29	0-255	R, G, B, W, Y, P dimming





		B, C key to modify the voice control sensitivity
10	R200	Red color selection, (000-255)
		B, C key to modify the color value
11	G200	Green color selection, (000-255)
		B, C key to modify the color value
12	B200	Blue color selection, (000-255)
		B, C key to modify the color value
13	W200	White color selection, (000-255)
		B, C key to modify the color value
14	Y200	Yellow color selection, (000-255)
		B, C key to modify the color value
15	ID01	Fixture ID, (01-14)
		B, C key to modify the ID value (for horse racing effect, can achieve multiple lights)

## Product Introduction

- \* Power Supply:AC90--275V,50--60HZ
- \* Power consumption:324WW
- \* Fixing lamp:LED Wall Wash 18x18W RGBWA+UV Lighting
- \* DMX-Control-channels:29/11/108/119 DMX Channels
- \* Shuttle:Flash rate:0--10HZ
- \* Dimmer:0-100% mechanic dimmer
- \* Long Lifespan LEDs(more than 60,000 hours)